

ClearVu Install Guide

4Runner (2010-2024) — PN: J-101

Kit Includes

- Installation instructions
- 8 ft. OEM-grade washer fluid hose
- Vehicle-specific drill template
- T-fitting
- Check valve
- (2) Zip ties
- J-101 spray nozzle

Installation Steps

- 1 Park on a level surface and disconnect the negative battery terminal.
- 2 Locate the rear washer fluid line near the rear hatch.
- 3 Use the included vehicle-specific drill template to mark the nozzle location.
- 4 Drill the mounting hole and seat the J-101 spray nozzle.
- 5 Tap into the washer line using the T-fitting and check valve.
- 6 Route the 8 ft. hose along factory channels and secure with zip ties.
- 7 Reconnect the battery and test using your factory wiper button.

Support: support@clearvucam.com — Buffalo, NY · USA